

BearCreeks BCBA03 4+1 Bite Alarm

Bite alarm units

- 8 tones settings
- 8 volume settings
- 5 sensitivity settings
- 15 sec latching LED
- 8 magnet rollers
- Running LED (all are white)
- Push button LED dimmer
- Black satin smooth finish
- Colorful light rollers
- 150-200 meters
- Operates with the 1.5V * 3 batteries
- 2.5mm jack socket
- Memory function in bite alarm
- Toggle switch
- Removable storm ears
- Low battery function



Technical Specification

Transmitter:

Power Voltage: 1.5 V * 3

Standby Current: 6uA

Working current: 58mA

Shut down current: 0mA

Working Power: 9dB

Frequency: 433MHz

Receiver:

Power voltage: 1.5V *3

Standby Current: 2.6mA

Working current: 21mA

Shut Down Current: 0mA

Alarms User Instructions

Inserting battery

Undo single battery ----- slide down battery cover ----- insert 1.5V * battery.

To complete the procedure, gently push back the battery cover.

Power on/off switch

Push the switch to right "Power ON", push the switch back left position "Power OFF"

Volume adjustment

Press the volume control "V" to step through the 8 volume settings, ranging from low to high and silent mode.

Tone adjustment

Press the tone adjustment button "T" to step through the 8 settings.

On/Off Light switch

Press the light control "L" to set ON/OFF night light.

Sensitivity adjustment

Press the sensitivity adjustment button "S" to step the 5 sensitivity settings, ranging from Minimum to Maximum mode - 1 beep equals maximum sensitivity to 5 beeps minimum sensitivity.

Run indication / Low battery indication

When magnet roller wheel is activated. Both LED's will be illuminated. The latching LED will illuminate for 20 seconds, and the run LED illumination stops when the roller wheel finishes rotating.

/ Run LED on bite alarm will flash /blink once every 5 seconds when battery is low.

Receiver units

- 8 tones settings
- 8 volume settings
- 5 colors clear LED choices
- Vibration mode/Silent mode
- 5 LED dimmer
- 150-200 meters



Receiver User Instructions

Inserting battery

Undo single battery ----- slide down battery cover ----- insert 1.5V * battery. To complete the procedure, gently push back the battery cover,

Power on/off switch

Push the switch to right "Power ON", push the switch back left position "Power OFF"

Volume adjustment

Press the volume control "V" to step through the 8 volume settings, ranging from low to high and silent mode.

Tone adjustment

Press the tone adjustment button "T" to step through the 8 settings.

On/Off Light switch

Press the light control "L" to set ON/OFF Bright Latching LED's.

Vibration adjustment

Press the vibration button "O" to choose vibration mode on or off.

Low battery indication

The first latch LED on remote receiver will flash/blink once every 5 seconds when battery is low.

Learning method

1. Press the `V` button and hold down `L` button, sounds one time, then enter the learning, the receiver receive a signal while rotate the roller wheel of bite alarm, it will sounds again , that means learning successfully , when you need to learn other bite alarm, repeat the above operation .

2. Press the `V` button and hold down `L` button, sounds one time, then enter the learning, press `L` button to choice receiver LED light while rotate the roller wheel of bite alarm, it will sounds again , that means learning successfully , when you need to Learn other bite alarm, repeat the above operation .

Erase method

Press the `V` button and hold down L button, sounds one time, then enter the learning, but continue hold down the buttons, sounds again, erasing successfully , and all code of bite alarm which had been stored are erased .

You can find more articles for a new genre of fishing on our website: <https://www.bearcreeks.com/>



BearCreeks GmbH

Marie-Curie-Str. 6, 85055 Ingolstadt, Deutschland
Web: www.bearcreeks.com E-Mail: sales@bearcreeks.com
Facebook: <https://www.facebook.com/BearCreeksGmbH/>
Instagram: <https://www.instagram.com/bearcreeks/>
LinkedIn: <https://www.linkedin.com/company/72937891/>
YouTube: https://www.youtube.com/channel/UC9GZ_NBgjUXu0Tv2eY5GmNw/videos